

Generic Options Assessment for: Brockenhurst (BROC)



Planning Objectives		2020	Driver	2050	Type of Measures	Generic Option Categories	Icon	Take Forward?	Reasons	Examples of Generic Options
PO1	Internal Flooding	0	-	-	Source (Demand) Measures (to reduce likelihood)	Control / Reduce surface water run-off		Y	-	Natural Flood Management; rural land management and catchment management; SuDS including blue and green infrastructure; storm management
PO2	Pollution Risk	0	-	-		Reduce groundwater levels		N	Reducing groundwater levels would reduce the risks from infiltration into the network. However, in practice, reducing groundwater levels will be detrimental to the environment, ground conditions and is prohibitively too costly to implement. For these reasons, this generic option has been discounted.	Reduce leakage from water supply pipes; pump away schemes to locally lower groundwater near sewer network
PO3	Sewer Collapse	0	-	-		Improve quality of wastewater		N	Reducing groundwater levels would reduce the risks from infiltration into the network. However, in practice, reducing groundwater levels will be detrimental to the environment, ground conditions and is prohibitively too costly to implement. For these reasons, this generic option has been discounted.	Domestic and business customer education; incentives and behaviour change (reduce Fats, Oils & Grease, wet wipes etc.); monitoring trade waste at source; on-site black water and/or greywater pre-treatment
PO4	Risk of Sewer Flooding in 1 in 50 yr	1	Hydraulic	1		Reduce the quantity / demand		Y	-	Water efficient appliances; water efficient measures; blackwater and/or greywater re-use; treatment at source
PO5	Storm Overflow Performance	2	Hydraulic	2	Pathway (Supply) Measures (to reduce likelihood)	Network Improvements		Y	-	Asset optimisation; additional network capacity; storage; separate flows; structural repairs; re-line sewer pipe and manholes; smart networks.
PO6	Risk of WTW Compliance Failure	0	-	0		Improve Treatment Quality		Y	-	Increase treatment capacity; rationalisation of treatment works (centralisation / de-centralisation); install tertiary plant; UV plant or disinfection facilities; innovation; improve Technical Achievable Limits; new WTWs
PO7	Annualised Flood Risk/Hydraulic Overload	0	-	0		Wastewater Transfer to treatment elsewhere		N	The causes of risk are not due to where our systems discharge to the environment or our ability to increase the capacity to connect more homes. Transferring wastewater for treatment elsewhere will not reduce any of the significant risks in this catchment.	Transfer flow to other network or treatment sites; transport sewage by tanker to other sites
PO8	DWF Compliance	0	-	1	Receptor Measures (to reduce consequences)	Mitigate impacts on Air Quality		N/A	Not included in first round of DWMPs	Carbon offsetting; noise suppression /filtering; odour control and treatments
PO9	Achieve Good Ecological Status	0	-	-		Improve Land and Soils		N/A	Not included in first round of DWMPs	Sludge soil enhancement
PO10	Improve Surface Water Management	0	-	-		Mitigate impacts on receiving waters		Y	-	River enhancement, aeration
PO11	Secure Nutrient Neutrality	2	Unknown	2		Reduce impact on properties		Y	-	Property flood resilience; non-return valves; flood guards / doors; air brick covers
PO12	Reduce Groundwater Pollution	0	-	-	Other	Study / Investigation		Y	-	Additional data required; hydraulic model development; WQ monitoring and modelling
PO13	Improve Bathing Water Quality	NA	-	-						
PO14	Improve Shellfish Water Quality	NA	-	-						

August 2021
Version 1